

## Specifications

Product Type: Cannabis All-In-One  
Dimension: 116\*24\*12mm (2ml)  
105.2\*24.0\*12.5mm (0.5ml/1.0ml)  
Tank Capacity: 0.5ml/1.0ml/2.0ml  
Battery Capacity: 380mAh  
Tank Material: PCTG  
Mouthpiece Material: PCTG  
Preheat Duration: 5 Seconds  
Material: PCTG + Aluminum Alloy  
Heating Element: Ceramic Coil  
Output: Variable Voltage  
Charging Port: Type-C  
Draw Mode: Autodraw

## Filling Instructions



- ① Fill the oil into the central filling hole (make sure the oil does not exceed the chamber's capacity).
- ② Attach the mouthpiece to the oil chamber from the top down.
- ③ Secure the silicone plug on the mouthpiece.


### Note:

- Do not fill oil into the two side airpaths.
- Use an injection needle with a diameter no greater than 2.5mm.
- Clean any oil drips immediately to prevent mess.
- Attach the mouthpiece within 30 seconds or as quickly as possible after filling to avoid leaking or clogging.
- Ensure the mouthpiece is securely attached with no visible gaps.



# Novo Pro User Manual

## Function Instructions



Power On/Off: Click × 5

Preheat: Click × 2

Voltage Adjustment: Click × 3

Green = Low    Blue = Medium    Red = High

1. Power On/Off: Click the button 5 times rapidly to turn on/off.
2. Preheat Mode: 2 clicks to start an 5-second preheat. The preheat icon lights up.
3. Voltage Adjustment: Click the button 3 times rapidly to switch voltage levels. The indicator light will flash 3 times.

### Note:

- The device will automatically shut off after 15 minutes of inactivity.
- Preheating will stop if any operation is performed or the device is charged.

## Display Instructions



## During Inhalation

The screen displays the current voltage and power (the red battery icon remains on when the battery is low).



The red battery icon stays on.

## Charging Instructions

1. During Charging: The display screen lights up and the battery icon flashes.



Flashes

2. Charging Complete: The display screen turns off once charging is complete. When the power cable is removed, the screen flashes 3 times.

### WARNING

1. The battery icon flashes red 10 times needs to be charged.
2. Insufficient battery level or voltage may lead to suboptimal performance. Please recharge the device promptly.
3. Use the original charging cable. Avoid fast chargers or adapters over 5 Volts/2 Amps.
4. Don't leave the device unattended while charging. Do not use the device while charging.
5. Keep the device at close to room temperature. Avoid extreme heat or cold (extreme heat may cause explosions). Store away from direct sunlight for long periods.
6. Do not use if the device is damaged, wet, or has been dropped. Do not disassemble or modify it.